

Box 10087  
Lloydminster, AB T9V 3A2  
Ph: (780) 205-7368  
Fx: (780) 875-1838  
www.thetentguys.net



## Snow Cone

### Snow Cone Machine Information Sheet

#### ELECTRICAL REQUIREMENTS:

- The snow cone machine requires a 15 amp, 110 volt outlet.

#### HOW TO OPERATE:

1. Place machine on a sturdy surface and plug machine directly into outlet. Do Not use an extension cord!
2. Remove the drainage hose from inside the cabinet part of the machine. Attach the drainage hose to the bottom of the cabinet and place the end into a pail (this collects the water that results from melting ice).
3. Fill the Ice Chute with ice.
4. Depress the Leaver – **DO NOT put anything else in the Ice Chute/Grinder area** as serious injuries could result.
5. Turn grinder switch “ON” and apply continuous pressure on the leaver.
6. Turn grinder switch “OFF”.
7. Repeat steps 3 to 6 as necessary.

#### TO MAKE A CONE:

1. Allow the ice to start to melt before scooping – this allows for easier formation of the snow cone.
2. Use a ladel to gather a ball of ice and pack it in a paper cone.
3. Dispense the desired amount of flavouring on the snow cone and serve.

#### CLEANING INSTRUCTIONS

- Wipe down the machine with warm water.
- Remove the drainage hose and place inside the cabinet part of the machine

THE TENT GUYS WILL NOT ASSUME ANY LIABILITY FOR INJURY DUE TO CARELESS HANDLING OR OPERATION OF THIS EQUIPMENT

Should any problems arise or if you have any questions contact us anytime at (780) 205-7368.